

USER MANUAL

PURE SINE WAVE INVERTER

8KW-30KW

Inverter & AC Charging

Contents

1 Safety Precautions	1
2 Installation	3
2.1 Inspection For Unpacking	3
2.2 Installation Requirements	3
2.3 Product Overview	4
2.4 Inverter Circuit Diagram	5
3 Operating	6
3.1 Inverter Screen Function	6
3.2 LCD Display Icons	7
3.3 System Standby	7
3.4 Display Data	8
3.5 LCD Setting	9
3.6 Language Setting	11
3.7 System Mode Setting	11
3.8 Battery Type Setting	13
3.9 Charging Current Setting	14
3.10 Alarm Setting	14
3.11 Clock Setting	15
3.12 Record Query	15
3.13 Record Delete	16
3.14 Factory Recover Setting	16
4 Troubleshooting	17
5 Protection And Cleaning	19
6 Removal	20
7 Technical Data Sheet	21

Chapter 1 Safety Precautions

Safety Of Operation

1. Please read this instruction carefully before use this inverter to ensure correct installation and safe operation.
2. Please pay attention to any warning signs and unusual when using this inverter.
3. Please don't place this inverter under direct sunlight, rain or moisture environment.
4. Please don't install this inverter near heat/heater/furnaces etc.
5. Please Install this inverter in a safe and empty space to ensure ventilation and heat dissipation , also easy to maintenance.
6. Please use dry and insulating rag to clean.
7. In the case of fire, please use a dry powder fire extinguisher to put out fire. Liquid fire extinguisher is prohibited.
8. Please choose a right space for the inverter installation and Battery pack powerful enough for the inverter.
9. Please make sure the appliances and battery capacity matches inverter rated power.

Prohibition

1. Please don't open the inverter shell if without authorization. The inverter inbuilt with high voltage component. If failed to follow instruction, there will be possibilities for electric shock and void of warranty.
2. If your appliances as follow, please consult with your local dealer or distributor before you install this inverter about its application/set-up/management and maintenance.
 - 1) Precision industrial/scientific and medical instruments or equipment.
 - 2) Elevators and other equipment that may endanger personal safety.
 - 3) Equipment that start up with large current and generating negative work.
3. Don't place the battery into fire to avoid explosion.

Safety Of Electric

1. Please make sure inverter been properly grounded and all cable connect in the right socket, also the battery polarity in the right position.
2. To protection your battery , please place a circuit breaker with over-current protection between inverter and battery.
3. If need reconnect the inverter cable, please make sure inverter is completely shut down and input breaker /battery switch is off, failed to follow this procedure , there will be possibilities for electric shock.

Safety Of Battery

1. The life span of the battery will be shortened if environment temperature increases. Replace battery regularly will make sure inverter working normally and ensure enough backup power.
2. The replacement and maintenance of battery must be made by authorized battery expertise. Must be same type of battery and same capacity with the same quantity.
3. There will be possibilities for electric shock and short-circuit, in order to avoid that, please follow below instruction.
 - A. Please remove your watch/ring/earring or any metal accessory.
 - B. Please use insulated tools.
 - C. Please wear rubber shoes and gloves.
 - D. Please don't place any metal tools or any metal component on the battery.
 - E. Please shut down all appliances before remove battery terminals.
 - F. Non-professionals please don't disassemble battery or damage battery, battery contain dangerous acid which could cause damage to the skin and eyes. If touch accidentally, please wash it off with water and go to hospital for more medical examination.
 - G. Please second confirm the battery cable positive and negative terminals before connect to battery.
 - H. Please install circuit breaker on battery to prevent fire and electrical shock.

Operation And Maintenance

1. The operation and storage environment is concerning the inverter life span and reliability. Therefore, please do not place the inverter in following environment:
 - A. Temperature/humidity exceed Inverter working environment standard. Inverter could work in be 0-55°C、0-95% humidity environment with no condensation.
 - B. Any place where will be vibration and collision.
 - C. Any place where metallic dust/corrosive substances/salt and flammable gasses.
2. Inverter must storage in dry environment if not use for certain amount of time.
3. The environment temperature must increase above 0°C for 2 hours before start up the inverter.
4. Please keep the inverter ventilation holes open, so inverter could ventilize. Insufficient of air will cause inner temperature go up and shorten inner component life span so does the inverter.
5. If not use battery for long time , pls recharge battery for every 3 months.


Chapter 2 Installation

2.1 Inspection For Unpacking

1. Open the package, carton should included following item:

- 1) Inverter one set
- 2) User manual one unit


2. Before opening the inverter package, please check and confirm if the inverter damaged during transportation. If any damaged or missing parts, please contact local dealer or distributor.

 **Recycling:** The carton packing is reusable, please don't throw away.

2.2 Installation Requirements


1. Please make sure it's professional electrician install this inverter. With following instruction:

- 1) Please do not place anything on top of the inverter.
- 2) The installation space should match the inverter size.
- 3) Please do not install the inverter on the wall which made by flammable or heat-resistant material.
- 4) Please install the inverter as picture show for easy inspection and maintenance.
- 5) Please do not install the inverter under direct sunlight.
- 6) Install environment humidity should be 0-95% with no condensation.
- 7) Environment temperature should be 0-55°C.
- 8) Please leave enough space between the inverter as picture shown.




 Above mentioned only suitable for ground mounted or other non-flammable surfaces.

2.3 Product Overview



[8-10KW]


[15-20KW]



[30KW]

1. RS485 Communication Port
2. Battery Switch
3. AC Switch
4. GND
5. AC Output
6. AC Input
7. Battery In

2.3.1 Device side - female connector




Pin on Rj45	Name	Description
1	A	Generator terminal 0
2	B	Generator terminal 1
8	GND	Signal and optional Power Supply common

2.4 Inverter Circuit Diagram

The machine with relatively high power is connected to the mains input and load output through the terminal block. The load output is output in addition to the terminal block mode.


Caveat! Please do not connect the output line to the "AC" terminal, and do not connect the AC to the "load" terminal.

AC input and output load connection



Chapter 3 Operating

3.1 Inverter Screen Function



• Indicator status

Identification	Indicator light name	Status
①	AC	AC Normal
②	Battery	Flash:charging;Long bright:full
③	Inverter	Battery inverter power supply
④	Fault/Warning	Warning/work abnormal


• LCD Display—⑤ : Detailed display information

• Navigation keys: selection, opening, obtaining information, modifying system parameters, etc.

Identification	Navigation keys	Function
⑥	ESC	Return to the previous interface menu or exit the settings interface (do not save the settings)
⑦	UP	Page turning; switching options; adding settings value
⑧	Down	Page turning; switching options; minus setting values
⑨	Enter	Press and hold for 5 seconds to enter the setting interface; short press to confirm save or set to enter the setting submenu
⑩	Turn On/Off	Turn on or turn off the inverter

3.2 LCD Display Icons


The main interface description is as shown.



NO.	Description	NO.	Description
1	System Mode	6	Output Voltage
2	AC Input	7	Alarm Status
3	Battery	8	Load
4	AC Input Voltage	9	Load Capacity
5	Battery Voltage	10	Fault Info

3.3 System Standby

In the unattended mode, the battery voltage will be too low to enter the system standby.



3.4 Display Data

The LCD display information will be switched in turns by pressing "UP" or "DOWN" key. The selectable information is switched as below order: AC input parameter, battery parameter, output parameter, system information.

Icon	Parameter Interface	LCD display
①	AC Input Parameter	<div style="border: 1px dashed black; padding: 5px;"> <p style="text-align: center;">AC Input parameter</p> <p>Voltage: 222V</p> <p>Freq: 50Hz</p> <p>Status: AC input normal</p> </div>
②	Battery Parameter	<div style="border: 1px dashed black; padding: 5px;"> <p style="text-align: center;">Battery Parameter</p> <p>Battery Voltage: 218V</p> <p>Battery Capacity: 100%</p> <p>Charging Voltage: 219V</p> </div>
③	Output Parameter	<div style="border: 1px dashed black; padding: 5px;"> <p style="text-align: center;">Output Parameter</p> <p>Voltage: 222V</p> <p>Freq: 50Hz</p> <p>Status : Inverter output</p> </div>
④	System Information	<div style="border: 1px dashed black; padding: 5px;"> <p style="text-align: center;">System Information</p> <p style="text-align: center;">2022-08-05 20:03:55</p> <p>Hardware version: 1.00</p> <p>Software version : 1.00</p> </div>

3.5 LCD Setting


In the default main interface, long press "ENTER" button for 5s to select setting programs. Press "UP" or "DOWN" key the selectable information .

Icon	Parameter Interface	LCD display
①	Language setting	<p>Language setting</p>
②	System mode setting	<p>System mode setting</p>
③	Battery type setting	<p>Battery type setting</p>
④	Charging current setting	<p>Charging current setting</p>
⑤	Alarm setting	<p>Alarm setting</p>

Icon	Parameter Interface	LCD display
⑤	Clock setting	<p>Clock setting</p>
⑥	Record query	<p>Record query</p>
⑦	Record delete	<p>Record delete</p>
⑧	Factory recover setting	<p>Factory recover setting</p>

3.6 Language Setting

In the default main interface, long press the "ENTER" for 5 seconds to enter the setup menu, press "DOWN" to select the language setting and press the "ENTER" to confirm, press the "ESC" to return to the menu or wait after the pop-up is successful. 2 seconds automatically returns to the menu.



3.7 System Mode Setting

In the default main interface, long press the "ENTER" for 5 seconds to enter the setup menu, press the "DOWN" to select the system mode setting and press the "ENTER" to confirm, enter the mode selection press "DOWN" to select the option, pop-up settings After success, press the "ESC" to return to the menu or wait for 2 seconds to automatically return to the menu.


AC Priority Mode - The AC input (utility power/city grid) will supply power to AC output (appliances /load) first, and auto charge battery at the same time. Inverter will auto stop charging when battery been fully charged. When there is no AC input, inverter will auto switch to battery power supply.

Battery Priority Mode - The battery power will supply power to AC output (appliances/load). When battery voltage reach low voltage limit, if AC input is on, inverter will auto switch to AC input supply; If AC input is off, inverter will auto shut down. When battery voltage reach low voltage restore setting, inverter will auto switch back to battery supply.

ECO Mode - Similar to AC priority mode. When AC input (utility power/city grid) is off, the inverter will auto enter standby status when appliances capacity under 5% inverter capacity. Inverter will keep auto switch between on and standby status in order to detect if AC output (appliances/load) capacity over 5% of the inverter capacity. If the AC output capacity over this above mentioned limit, inverter will auto switch from standby status to inverting status.


Generator mode - use unstable generator to generate power, access the inverter AC input, through the inverter AVR regulator, automatic matching 50HZ/60HZ municipal frequency, output voltage regulator in the normal operating range.

Unattended Mode - Similar AC priority mode. When AC input (utility power/city grid) is off, battery voltage is too low, the inverter will auto shut down AC output and enter STANDBY status. Once battery been charged it back to the restore voltage point, the inverter will restart the AC output. On the other hand, when AC input back on, inverter will auto restart AC output as well.



3.8 Battery Type Setting


In the default main interface, the long press "ENTER" 5 seconds into the settings menu, press "DOWN" to select battery type settings and then press "ENTER" confirmation, enter mode select press "DOWN" selection option, Press "ESC" to return to menu or wait for 2 seconds to automatically return to menu.



3.9 Charging Current Setting

In the default main interface, long press the "ENTER" for five seconds to enter the setup menu, press the "DOWN" to select the charging current setting and press the "ENTER" to confirm, press the "DOWN" to modify the value, confirm the value and press to "ENTER", press the "ESC" to return to the menu after the pop-up setting is successful or wait for 2 seconds to automatically return to the menu.


(Note: setting the value to 0% will turn off the charging function)



Note: The rated current is 0%-100% of the maximum charging current.


3.10 Alarm Setting

In the default main interface, long press the "ENTER" for five seconds to enter the setup menu, press the "DOWN" to select the alarm tone setting and press the "ENTER" to confirm, press the "ESC" to return to the menu or Wait 2 seconds to automatically return to the menu.




3.11 Clock Setting

In the default main interface, long press the "ENTER" for five seconds to enter the setup menu, press the "DOWN" to select the clock setting and press the "ENTER" to confirm, press the "ESC" to return to the menu or Wait 2 seconds to automatically return to the menu.




3.12 Record Query

In the default main interface, the long press "ENTER" 5 seconds into the settings menu, press "DOWN" to select record query and then press "ENTER" confirmation, Press "ESC" to return to menu or wait for 2 seconds to automatically return to menu.




3.13 Record Delete

In the default main interface, the long press "ENTER" 5 seconds into the settings menu, press "DOWN" to select record query and then press "ENTER" confirmation, Press "ESC" to return to menu or wait for 2 seconds to automatically return to menu.



3.14 Factory Recover Setting

In the default main interface, long press the "ENTER" for five seconds to enter the setup menu, press the "DOWN" to select the factory recover setting and press the "ENTER" to confirm, press the "ESC" to return to the menu or Wait 2 seconds to automatically return to the menu.



Chapter 4 Trouble Shooting

When the inverter is not working properly, we recommend the following solutions to eliminate common faults. The table below helps the technician understand the problem and take action.

Problem	LCD/LED/Buzzer	Explanation / Possible cause	What to do
Unit shuts down automatically	No indication or buzzer beeps continuously and red LED is on	The battery voltage is too low	1. Re-charge battery. 2. Replace battery.
Fan stop or slow running	No indication	Fan intelligent speed regulation or fan fault	1. A rise in temperature or load capacity will increase the running speed. 2. Replace the fan.
Output turns on for 1 second and then stops, repeating	ECO mode	This mode shuts off output when the load is less than 5%	1.The load > 5% will run continuously. 2.Change mode settings.
No response after power on	No indication	1. The battery voltage is far too low. 2. Battery polarity is connected reversed.	1. Check if batteries and the wiring are connected well. 2. Re-charge battery. 3. Replace battery.
Mains exist but the unit works in battery mode	Input voltage is displayed as 0 on the LCD	Input protector is tripped	Check if AC breaker is tripped and AC wiring is connected well.
	Input voltage is displayed in the normal range on the LCD	Insufficient quality of AC power. (Shore or Generator)	1. Check if AC wires are too thin and/or too long. 2. Check if generator (if applied) is working well or The input frequency is unstable or out of range.
	Green LED is lighten	Set "Battery priority mode" as the system mode	System mode is not set to "Battery priority mode".
Buzzer beeps continuously and red LED is on	Over current	Over current or surge	Reduce the connected load ,Restart the unit, if the error happens again, please return to repair center.
	Output short	Output Short or surge	

Problem	LCD/LED/Buzzer	Explanation / Possible cause	What to do
Buzzer beeps continuously and red LED is on	Over load	Over load error. The inverter is over load 110% and time is up	Reduce the connected load by switching off some equipment.
	Over temperature	Internal temperature of inverter component is over 80°C	Check whether the air flow of the unit is blocked or whether the ambient temperature is too high.
	Battery volt. high	Battery is over-charged.The battery voltage is too high	1. Check the setting of charger. 2. Check if spec and battery quantity of requirements.
	Battery voltage low	The battery voltage is too low	1. Re-charge battery. 2. Replace battery. 3. Check if spec and battery.
	Output voltage low	Output abnormal	1. Reduce the connected load. 2. Return to repair center.

Chapter 5 Protection And Cleaning

Check The Heat Dissipation

Please check environment temperature around the inverter. Make sure there is no clogging of the vents.

Cleaning the inverter will improve the heat dissipation of the inverter.

Cleaning The Inverter

Please turn off AC input first, shut down inverter ,then turn off the DC switch. Make sure all of them is completely off.

You could wipe the inverter with dry and insulated rag. Please don't use water and any liquid such as solvent or abrasive liquid.

Check Connection

Please check all cables or breakers regularly to see if there is abnormal heat. If there any damage of the cable and breaker, pls shut down all of component and contact a professional electrician for inspection.

Chapter 6 Removal

How To Remove The Inverter

- Shut down AC input.
- Shut down inverter.
- Shut down DC breaker.
- Remove all cables off the inverter.
- Carefully remove the inverter.

Inverter Packaging

Please keep the inverter original packaging in case of delivery. If you can't find the original packaging ,please use strong box with correct size to contain this inverter.

Inverter Processing



Please do not throw this in the garbage. In case of dispose this inverter, please follow local regulations about electronic component recycling.

Chapter 7 Technical Data Sheet

Model		8KW	10KW	15KW	20KW	30KW
Capacity	Rated Power	8KW	10KW	15KW	20KW	30KW
	Peak Power	24KW	30KW	45KW	60KW	90KW
Input	Battery Voltage	96V		96V/192V /240V	192V/240V	
	DC Input Voltage	84-120VDC@96V / 168-240VDC@192V / 210-300VDC@240V				
	AC Input Voltage	165-275VAC@220V / 173-288VAC@230V / 180-289VAC@240V				
	AC Input Frequency	50Hz / 60Hz±5Hz				
Output	Effectiveness	≥85%				
	Output Voltage	(Inverter Mode) 220V / 230V / 240VAC±3%				
	Output Frequency	(Inverter Mode) 50Hz / 60Hz±0.5Hz				
	Output Waveform	Pure Sine Wave				
AC Charging	Type Of Battery	SLA Battery / AGM Battery / GEL Battery / Lithium Battery				
	AC Charging Current	15A				
Protection	Battery High Voltage Warning	96V : > 120VDC / 192V : > 240VDC / 240V : > 300VDC				
	Battery High Voltage Protection	96V : > 136VDC / 192V : > 272VDC / 240V : > 340VDC				
	Battery Low Voltage Warning	96V : < 84VDC / 192V : < 168VDC / 240V : < 210VDC				
	Low Voltage Battery Shutdown	96V : < 80VDC / 192V : < 160VDC / 240V : < 200VDC				
	Overload, High Temperature, Short Circuit Protection	Automatic Shutdown				
Other	Switchover Time	≤5ms				
	Display	LCD				
	Cooling System	Forced Air Cooling, Intelligent Speed Regulation				
	Operating Mode	AC Input Priority Mode / Battery Priority Mode / ECO Mode / Generator Mode / Unattended Mode				
	Communication	RS-485				
Working Environment	Temperature	0~55°C				
	Humidity	0~95%(No Condensation)				
Exterior	Product Size(mm)	756x334x620		874x382x679		934x382 x679
	N.W.(Kg)	51	56	100	117.5	129.5

• The technical specifications of this document are subject to change without any notice